


1.1 MAIN BODY ASSEMBLY

Model : UB-314




NO	Part No.	Part name	Q'ty	Remarks
	314CY01000	Cylinder ass'y	1	
1	314CY01010	Cylinder	1	
2	314CY01020	M24 heli-coil	4	
3	314CY01030	M20 heli-coil	10	
4	314CY01040	U-packing	1	
5	314CY01050	Buffer ring	1	
6	314CY01060	Dust seal	1	
7	314CY01070	Seal retainer	1	
8	314CY01080	Slide packing	2	
9	314CY01090	O-ring	2	
10	314CY01100	Seal-ring	1	
11	314CY01110	O-ring	3	
12	314CY01120	Back up ring	2	
13	314CY01130	Knock pin	3	
14	314CY01140	O-ring	4	
15	314CY01160	Teflon bushing	2	
16	314CY01170	Cylinder adjuster	1	
17	314CY01180	Adjuster nut	1	
18	314CY01190	O-ring	1	
19	314CY01200	Back up ring	1	
20	314CY01210	1/4 socket plug	4	
21	314CY01220	O-ring	4	
22	314CY01230	M24 socket plug	1	
23	314CY01240	O-ring	1	
24	314CY01250	7/8" Socket plug	1	
25	314CY01260	O-ring	1	
26	314CY01280	Piston	1	
	314VV02000	Valve ass'y	1	
27	314VV02010	Valve	1	
28	314VV02020	Valve housing	1	
29	314VV02030	O-ring	1	
30	314VV02040	Back up ring	1	
31	314VV02050	Valve cover	1	
32	314VV02060	O-ring	2	
33	314VV02061	O-ring	2	


NO	Part No.	Part name	Q'ty	Remarks
34	314VV02070	Back up ring	2	
35	314VV02080	O-ring	4	
36	314VV02081	Back up ring	4	
39	314VV02090	Valve adjuster	1	
40	314VV02100	Adjuster nut	1	
41	314VV02110	O-ring	1	
42	314VV02120	Back up ring	1	
43	314VV02130	1" socket plug	1	
44	314VV02140	O-ring	1	
45	314VV02150	1/4 socket plug	2	
46	314VV02160	O-ring	2	
47	314VV02170	Hollow plug	1	
48	314VV02180	Valve cover bolt	8	
49	314VV02190	Valve housing bolt	10	
	314AC03000	Accumulator ass'y	1	
50	314AC03010	Accumulator cover	1	
51	314AC03020	Accumulator body	1	
52	314AC03030	Diaphragm	1	
53	314AC03040	Holder ass'y	1	
54	314AC03050	Charging valve	1	
55	314AC03060	Charging valve cap	1	
56	314AC03070	O-ring	1	
57	314AC03080	O-ring	2	
58	314AC03090	Accumulator plug	1	
59	314AC03100	Acc. body bolt	4	
60	314AC03110	Acc. cover bolt	12	
61	314AC03120	O-ring	1	
62	314AC03130	Back up ring	1	
	314BC04000	Back head ass'y	1	
63	314BH04010	Back head	1	
64	314BH04020	Flange adapter	4	
65	314BC04030	Socket bolt	8	

4

Model : UB-314



2.1 CRADLE TYPE BRACKET (BOX TYPE)



No.	Part No.	Part Name	Q'ty	Remarks
	314BO0000	Bracket ass'y	1	
1	314BO0001	Bracket, main	1	
2	314BO0002	Bracket pin	2	
3	314BG0003	Bracket stop ring	2	
4	314BG0004	Bracket bush	4	
5	314BG0005	Stopping bolt	2	
6	314BG0006	Grease nipple	4	
7	314BT0007	Spacer bolt	4	
8	314BT0008	Spring washer	4	5.9t
9	314BO0009	Spacer	2	
10	314BO0010	Mounting cap	1	
11	314BO0011	Mounting cap bolt	16	
12	314BO0012	Spring washer	16	7.5t
13	314BO0013	Mounting cap nut	32	
14	314BO0014	Damper	1	
15	314BO0015	Damper cover	1	
16	314BO0016	Damper cover bolt	8	
17	314BO0017	Spring washer	8	5.9t
18	314BO0018	Top damper	-	
19	314BO0019	Front damper	1	
20	314BO0020	Bottom damper	1	
21	314BO0021	Rear damper(1)	1	
22	314BO0030	URETAN PAD	1	15t
23	314BO0023	Side damper(1)	2	
24	314BO0030	URETAN PAD	4	15t
25	314BO0025	Stopping nut	4	