


NO	Part No.	Part name	Q'ty	Remarks
	3121CY01000	Cylinder ass'y	1	
1	3121CY01010	Cylinder	1	
2	3121CY01020	M24 heli-coil	4	
3	3121CY01030	M20 heli-coil	8	
4	3121CY01040	U-packing	1	
5	3121CY01050	Buffer ring	1	
6	3121CY01060	Dust seal	1	
7	3121CY01070	Seal retainer	1	
8	3121CY01080	Slide packing	2	
9	3121CY01090	O-ring	2	
10	3121CY01100	Seal-ring	1	
11	3121CY01110	O-ring	3	
12	3121CY01120	Back up ring	2	
13	3121CY01130	Knock pin	3	
14	3121CY01140	O-ring	4	
15	3121CY01150	Teflon bushing	2	
16	3121CY01160	Cylinder adjuster	1	
17	3121CY01170	Adjuster nut	1	
18	3121CY01180	O-ring	1	
19	3121CY01190	Back up ring	1	
20	3121CY01200	1/4 socket plug	4	
21	3121CY01210	O-ring	4	
22	3121CY01220	M24 socket plug	1	
23	3121CY01230	O-ring	1	
24	3121CY01240	1 1/4 Socket plug	1	
25	3121CY01250	O-ring	1	
26	3121CY01260	Piston	1	
	3121VV02000	Valve ass'y	1	
27	3121VV02010	Valve	1	
28	3121VV02020	Valve housing	1	
29	3121VV02030	O-ring	1	
30	3121VV02040	Back up ring	1	
31	3121VV02050	Valve cover	1	
34	3121VV02060	O-ring	1	
35	3121VV02070	O-ring	3	

NO	Part No.	Part name	Q'ty	Remarks
36	3121VV02080	Back up ring	2	
37	3121VV02090	O-ring	4	
38	3121VV02100	Back up ring	4	
39	3121VV02110	Valve adjuster	1	
40	3121VV02120	Adjuster nut	1	
41	3121VV02130	O-ring	1	
42	3121VV02140	Back up ring	1	
43	3121VV02150	1 socket plug	1	
44	3121VV02160	O-ring	1	
45	3121VV02170	1/4 socket plug	2	
46	3121VV02180	O-ring	2	
47	3121VV02190	Hollow plug	1	
48	3121VV02200	Valve cover bolt	8	
49	3121VV02210	Valve housing bolt	10	
	3121AC03000	Accumulator ass'y	1	
50	3121AC03010	Accumulator cover	1	
51	3121AC03020	Accumulator body	1	
52	3121AC03030	Diaphragm	1	
53	3121AC03040	Holder ass'y	1	
54	3121AC03050	Charging valve	1	
55	3121AC03060	Charging valve cap	1	
56	3121AC03070	O-ring	1	
57	3121AC03080	O-ring	2	
58	3121AC03090	Accumulator plug	1	
59	3121AC03100	Acc. body bolt	4	
60	3121AC03110	Acc. cover bolt	12	
61	3121AC03120	O-ring	1	
62	3121AC03130	Back up ring	1	
	3121BC04000	Back head ass'y	1	
63	3121BH04010	Back head	1	
64	3121BH04020	Flange block assy	2	
	3121BH04021	Flange block	8	
	3121BH04022	O-ring	2	
	3121BH04023	Adapter	2	

Model : UB-312N



NO	Part No.	Part name	Q'ty	Remarks
	3121BH04024	O-ring	2	
66	3121BH04030	Socket bolt	8	
67	3121BH04040	Hose	2	
68	3121BC04060	B/Head charging V/V ASSY	1	
	3121BC04061	B/H charging valve	1	
	3121BC04062	O-ring	1	
	3121BC04063	Charging valve cap	1	
	3121BC04064	O-ring	1	
69	3121BH04070	Grease Line	1	
70	3121BH04080	Air plug ass'y	1	
	3121FH05000	Front head ass'y	1	
71	3121FH05010	Front head	1	
72	3121FH05020	Thrust bushing	1	
73	3121FH05030	Front head cover	1	
74	3121FH05040	Grease nipple	2	
75	3121FH05050	O-ring	2	
76	3121FH05060	Front head cover pin	2	
77	3121FH05070	Rubber plug	2	
78	3121FH05080	Spring pin	2	
79	3121FH05090	Stop pin	2	
80	3121FH05100	Rubber plug	2	
81	3121FH05110	Rod pin	2	
	3121TB06000	Through bolt ass'y	4	
82	3121TB06010	Through bolt	4	
83	3121TB06020	Round nut	4	
84	3121TB06030	Through bolt washer A	4	
85	3121TB06040	Hexagonal nut	4	
86	3121TB06050	Through bolt washer B	4	
87	3121RR07000	Rod (w)	1	
	3121RR07001	Rod (F)		
	3121RR07002	Rod (M)		
	3121RR07003	Rod (C)		
	3121SL00000	Seal kit	1	
	3121TL00010	Tool set	1	

No.	Part No.	Part Name	Q'ty	Remarks
	3121BC0000	Bracket ass'y.	1	
1	3121BC0001	Bracket, main	1	
2	3121BC0002	Bracket pin	2	
3	3121BC0003	Bracket stop ring	2	
4	3121BC0004	Bracket bush	4	
5	3121BC0005	Stopping bolt	2	
6	3121BC0006	Grease nipple	4	
7	3121BC0007	Spacer bolt	4	
8	3121BC0008	Spring washer	4	
9	3121BC0009	Spacer	2	
10	3121BC0010	Mounting cap	1	
11	3121BC0011	Mounting cap bolt	16	
12	3121BC0012	Spring washer	16	
13	3121BC0013	Mounting cap nut	32	
14	3121BC0014	Damper	1	
15	3121BC0015	Damper cover	1	
16	3121BC0016	Damper cover bolt	8	
17	3121BC0017	Spring washer	8	
18	3121BC0018	Top damper	1	
19	3121BC0019	Front damper	1	
20	3121BC0020	Bottom damper	1	
21	3121BC0021	Rear damper(1)	1	
22	3121BC0022	Uretan pad	2	
23	3121BC0023	Side damper(1)	2	
24	3121BC0022	Uretan pad	4	
25	3121BC0025	Stopping nut	4	