


1.1 MAIN BODY ASSEMBLY


Model : UB -316



NO	Part No.	Part name	Q'ty	Remarks
	316CY01000	Cylinder ass'y	1	
1	316CY01010	Cylinder	1	
2	316CY01020	M24 heli-coil※	4	
3	316CY01030	M20 heli-coil※	10	M20*P2.5*L1.5D
4	316CY01040	U-packing	1	
5	316CY01050	Buffer ring	1	
6	316CY01060	Dust seal	1	
7	316CY01070	Seal retainer	1	
8	316CY01080	Slide packing	2	
9	316CY01090	O-ring	2	
10	316CY01100	Seal-ring	1	
11	316CY01110	O-ring	3	
12	316CY01120	Back up ring	2	
13	316CY01130	Knock pin※	3	
14	316CY01140	O-ring※	4	
15	316CY01160	Teflon bushing※	2	
16	316CY01170	Cylinder adjuster※	1	
17	316CY01180	Adjuster nut※	1	
18	316CY01190	O-ring※	1	
19	316CY01200	Back up ring※	1	
20	316CY01210	1/4 socket plug※	4	
21	316CY01220	O-ring※	4	
22	316CY01230	M24 socket plug※	1	
23	316CY01240	O-ring※	1	
24	316CY01250	1 1/4 Socket plug※	1	
25	316CY01260	O-ring※	1	
26	316CY01280	Piston	1	
	316VV02000	Valve ass'y	1	
27	316VV02010	Valve	1	
28	316VV02020	Valve housing	1	
29	316VV02030	O-ring※	1	
30	316VV02040	Back up ring※	1	
31	316VV02050	Valve cover	1	
32	316VV02060	O-ring※	2	

NO	Part No.	Part name	Q'ty	Remarks
33	316VV02061	Back up ring	2	
34	316VV02070	O-ring*	2	
35	316VV02080	O-ring*	4	
36	316VV02081	Back up ring*	4	
37				
38				
39	316VV02090	Valve adjuster*	1	
40	316VV02100	Adjuster nut*	1	
41	316VV02110	O-ring*	1	
42	316VV02120	Back up ring*	1	
43	316VV02130	1 socket plug*	1	
44	316VV02140	O-ring*	1	
45	316VV02150	1/4 socket plug*	2	
46	316VV02160	O-ring*	2	
47	316VV02170	Hollow plug*	1	
48	316VV02180	Valve cover bolt*	8	
49	316VV02190	Valve housing bolt*	10	
	316AC03000	Accumulator ass'y*	1	
50	316AC03010	Accumulator cover	1	
51	316AC03020	Accumulator body	1	
52	316AC03030	Diaphragm	1	
53	316AC03040	Holder ass'y	1	
54	316AC03050	Charging valve	1	
55	316AC03060	Charging valve cap	1	
56	316AC03070	O-ring	1	1BP 5
57	316AC03080	O-ring	2	
58	316AC03090	Accumulator plug	1	
59	316AC03100	Acc. body bblt	4	
60	316AC03110	Acc. cover bolt	12	
61	316AC03120	O-ring	1	
62	316AC03130	Back up ring	1	
	316BH04000	Back head ass'y	1	
63	316BH04010	Back head	1	
64	316BH04020	Flange adapter*	4	

Model : UB - 316



NO	Part No.	Part name	Q'ty	Remarks
65	316BH04030	Socket bolt※	8	
66	316BH04040	O-ring※	2	
67	316BH04050	Hose※	2	
68	316BH04060	B/Head charging V/V SET※	1	
69	316BH04070	Grease Line	1	
70	316BH04080	Air plug ass'y※	1	
	316FH05000	Front head ass'y	1	
71	316FH05010	Front head	1	
72	316FH05020	Thrust bushing※	1	
73	316FH05030	Front head cover※	1	
74	316FH05040	Grease nipple※	2	Grease nipple
75	316FH05050	O-ring	2	
76	316FH05060	Front head cover pin※	2	
77	316FH05070	Rubber plug※	2	φ 30
78	316FH05080	Spring pin※	2	
79	316FH05090	Stop pin※	2	
80	316FH05100	Rubber plug※	2	φ 20
81	316FH05110	Rod pin	2	
	316TB06000	Through bolt ass'y	4	
82	316TB06010	Through bolt	4	
83	316TB06020	Round nut	4	
84	316TB06030	Through bolt washer A	4	
85	316TB06040	Hexagonal nut	4	
86	316TB06050	Through bolt washer B	4	
87	316RR07000	Rod (w) ※	1	
	316RR07001	Rod (F)		
	316RR07002	Rod (M)		
	316RR07003	Rod (C)		
	316SL00000	Seal kit	1	